


Fix the guy lines with pegs, and fix the top pole

If you have any questions or more good ideas, please open the link(www.iodoland.com) or send emails to our customer service (cs@iodoland.com).





Thank you for your purchase of ODOLAND camping tent. Please refer to this quick guide before you use it.



**Step 1:** Pick up two long poles and cross through the canopy.



Step 2:
Insert the poles into the metal ring of tent in bottom corners, then buckled the plastic hook to the poles, and tied the two poles with the rope at the top finally.



Hook the buckles of fly to the metal ring of tent in bottom corners, and tie the straps of fly to the poles..